



"The Original"
Pkg. of 4
"The Ultimate Release"

OR10
ADJUSTABLE LIGHT TENSION PLANER
BOARD AND IN LINE PLANER BOARD
RELEASE WITH QUICK CLIP AND SPLIT
RING, YELLOW

You can adjust the tension of the release by positioning the spring as shown below.



Heavy Tension



Light Tension


Made in the U.S.A.



HOW TO USE YOUR PLANER BOARD OR IN LINE PLANER BOARD RELEASE


With In Line Planer Boards:

Attach the OR10 to the tow point of the in line planer board (use a split ring if needed for attachment).



With Planer Boards:

Attach the quick clip to the planer board tow line, then place the fishing line in the release and let the release slide down the tow line toward the planer board.



Use ORRP16 replacement pads.



**OFF SHORE TACKLE COMPANY LLC
PORT AUSTIN, MI**