




OR10BWW
ADJUSTABLE LIGHT TENSION PLANER BOARD RELEASE
WITH QUICK CLIP AND SPLIT RING, YELLOW
(Retail package will contain 100 Yellow Releases, 100 Quick Clips and 100 Split Rings). To order replacement pads for your OR10, order part number: ORRP16.


HOW TO USE YOUR PLANER BOARD PLANER BOARD RELEASE

You can adjust the tension of the release by positioning the spring as shown below.



On dual or triple planer boards, attach the quick clip to the planer board tow line by choosing one of the options below, then place the fishing line in the release and let the release slide down the tow line toward the planer board until it reaches your desired location. You can spread up to 6 lines over a 150 foot area with a good planer board rig.

You can also use the OR10 on in line planer boards (use the split ring provided if needed).



PAD CARE

For long storage, place a piece of cardboard between the pads to keep them from sticking together or being pulled off. Use ORRP16 replacement pads.