




**OR14BWW
ADJUSTABLE MEDIUM TENSION PLANER BOARD AND
IN LINE PLANER BOARD RELEASE WITH QUICK CLIP AND
SPLIT RING, BLACK**

(Retail package will contain 100 Black Releases, 100 Quick Clips and 100 Split Rings).
To order replacement pads for your OR14, order part number: ORRP16.


You can adjust the tension of the release by positioning the spring as shown below.



HOW TO USE YOUR PLANER BOARD OR IN LINE PLANER BOARD RELEASE

On dual or triple planer boards, attach the quick clip to the planer board tow line by choosing one of the options below, then place the fishing line in the release and let the release slide down the tow line toward the planer board until it reaches your desired location. You can spread up to 6 lines over a 150 foot area with a good planer board rig.

You can also use the OR14 on in line planer boards (use the split ring provided if needed).



PAD CARE

For long storage, place a piece of cardboard between the pads to keep them from sticking together or being pulled off. Use ORRP16 replacement pads.